




## Legend

### Compatibility Zones

- Airport Influence Area Boundary
- Zone A
- Zone B1
- Zone B2
- Zone C
- Zone D
- Zone E
- Height Review Overlay Zone

### Boundary Lines

- Airport Property Line
- City Limits
- Cathedral City City Limits

### Notes

All dimensions measured from runway ends and centerlines.

DT = Displaced Threshold